## AHP-1200MSP

# **Magnetic Stirring Cold/Hot Plate**

Air Cooled Bench Top Input: 100-240 VAC; Max. Power: 600 Watts

#### **FEATURES**

- · Heating and cooling
- Unique high-performance side mounting cold plate for added cooling and uniform temperatures
- Magnetic drive for stir bars from underneath the vessel
- Magnetic stir speed range 100-1400 RPM
- Integral PWM temperature controller
- Variable speed fan for reduced noise
- Weighs less than 50 lbs. (23 kg)
- Compact bench-top design
- No compressor, fluorocarbons or filters
- Virtually maintenance-free operation
- Painted and brush finished stainless steel exterior
- Use with one of five cold shoe direct contact blocks
- Use with ICE-1200MSP Ice Bucket and Thermal Lab Beads<sup>TI</sup>
  OR
- Use cold shoe and bucket together for easy beaker access
- Either cold shoe accessory or Ice Bucket accessory is required (order separately)!
- IEC 61010-2-010, IEC 61010-1, UL 61010-1, CSA C22.2#61010-1-12
- FCC 47CFR Part 15 Subpart B. EN 61326-1\*BEI

### CONTROL FEATURES

- Integral "tunable" PWM temperature control
- PWM, Bi-directional temperature control
- 4 Temperature zone with 4 independent PID settings
- Multi-segment ramp and soak programmable
- Internal RTD sensor
- Remote Sensibility™ switchable to exterior accessory RTD sensor
- USB Communication with easy to use software

#### **ICE BUCKET ACCESSORY**

The ICE-1200MSP ice bucket accessory converts the AHP-1200MSP into stirring ice bucket which can cool and heat many sizes and types of vessels while mixing the contents. The stirring bead bath uses aluminum Thermal Lab Beads™ instead of water to conduct the heat away from your beaker or vial and a magnetic stir bar to stir the contents. Two liters of tecaLAB Thermal Lab Beads™ are included with the accessory.





#### **COLD SHOE ACCESSORY**

A cold shoe accessory converts the AHP-1200MSP into a direct contact cooler for specific diameter vessels. This provides a faster reaction time, wider temperature range (-10 °C to 50 °C) and better temperature control.


Use cold Shoe with Ice Bucket together for easy beaker removal and fixturing.

### **SPECIFICATIONS**

MODEL	PART NUMBER	NOTES	VOLTAGE VAC 50/60 HZ	CURRENT AMPS.	WEIGHT LBS. (KG)	TEMP. CONTROL	OPERATING AMBIENT °C
AHP-200MSP	9-35KB-1-MSP	Heat/Cool	100-240	6.0 - 2.5	26 (12)	TC-5300	0-45

- The AHP-1200MSP must be used with either ICE-1200MSP Ice Bucket or one of the SLV-XXXMSP Cold Shoe accessories.
- Use Cold Shoe and Ice Bucket together for easy beaker fixturing and removal.

## AHP-1200MSP



AHP-1200MSP with cold shoe accessory

Soft pliable Thermal Transfer Pads (TT PADS) conform to the vessel. Thermal Transfer Pads are included with the cold shoe accessories.

PART NUMBER	BEAKER TYPE	VOLUME mL	BEAKER DIAMETER in [mm]	BEAKER HEIGHT in [mm]
SLV-1000LMSP	Griffin Low Form	1000	4.25 [108]	6.2 [158]
SLV-1000HMSP	Berzelius Tall Form	1000	3.5 [89]	7.36 [187]
SLV-1500MSP	Griffin Low Form	1500	4.76 [121]	6.5 [166]
SLV-2000MSP	Griffin Low Form	2000	5.16 [131]	7.6 [193]
SLV-3000MSP	Griffin Low Form	3000	5.75 [146]	8.5 [216]
SLV-4000MSP	Griffin Low Form	4000	6.3 [160]	9.8 [250]
SLV-5000MSP	Griffin Low Form	5000	6.7 [170]	10.6 [270]

