



## Mounting, Monture, Montage, Montaggio



## Alternate, Alternative, Alternative, Alternativa



### Notes:

- Lay out the mounting cutout and holes on one of the panels of the enclosure. Note the different size (smaller) guide holes. Reference Mounting Cutout drawing SK130301.
- Using an appropriate cutting tool cut the mounting cut out and drill the holes.
- Install (2) longer guide studs (10-32 X 1") on the AHP-6200 mounting flange, in the two opposite corners matching the two Ø0.281 guide holes of the cutout.
- Install the remaining (28) stud (10-32 X 3/4") on the AHP-6200 mounting flange.
- Place the mounting gasket on the AHP-6200 mounting flange, the studs will keep the gasket in place.
- Align the two guide studs with the two guide holes of the mounting cutout.
- Push the AHP-6200 through the cutout making sure the two guide studs go through the guide holes in the cutout.
- Once the guide studs clear the guide holes the rest of the studs will line up and clear the mounting holes.
- Push the AHP-6200 flush too the enclosure surface.
- From inside the enclosure install the 10-32 flat washers, 10-32 lock washers and 10-32 Hex nuts on the studs and tighten in an "X" pattern.

INFORMATION DISCLOSED HEREIN IS THE CONFIDENTIAL PROPERTY OF TECA CORP. RECIPIENT SHALL NOT USE THE INFORMATION IN ANY UNAUTHORIZED MANNER.	UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:		<b>THERMOELECTRIC COOLING AMERICA CORP.</b>	
	DECIMALS	ANGLE	<b>AHP-6200 SERIES INSTALLATION</b>	
	.XX +/-	+/-		
	XXX +/-	FRACTION +/-		
FINISH:	MATERIAL:	DRAWN BY: AA	DRAWING # SK130302	REV LEVEL
		DATE: 03/07/2013	SCALE	MASTER: SK130301
		D8653		SHEET

REV	DESCRIPTION	Date	APPROVED