


# AHP-1200CPV & CWB-01 PID settings P=45 I=1200 D=0



— Set Point — Cold Plate — Bottle #2 — Bottle#3 — dT Plate - Bottles — dT Set Point - Bottles